




WTB-004 Universal Compact Sustain Pedal Owner's Manual

Thank you for choosing Cherub WTB-004 compact sustain pedal. It's a universal sustain pedal designed to operate as sustain pedal / sustain pedal for electronic musical instruments (including but not limited to the following devices: electronic pianos, MIDI keyboards and Synthesizer.) It can also be used as a hands-free on/off switch for activating effects.

Features

- High quality metal housing with anti-slip rubber base.
- Polarity switch for universal compatibility.



Polarity switch

Operation Instruction

1. Please check the polarity of the instrument you're going to play with.
2. Please make sure that the polarity of WTB-004 and your instrument are same before connecting them together.
3. Press and hold down the foot switch / sustain pedal as long as you would like to perform its function.

Specifications

- Cord: 2000mm, 6.35mm input jack
- Dimensions: 97(L)X72(W)X28(H)mm
- Weight: 284g

* Specification may change without notice.

Precautions

- Avoid using in high temperature, humidity, fog and other harsh environments.
- Do not disassemble the unit, intentionally artificial damage is not covered by the warranty.
- Please keep this manual for further reference.

Accessories

- Owner's manual

THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE mark for European Harmonized Standards

CE Mark which is attached to our company's products of Battery mains the product is in fully conformity with the harmonized standard(s) EN 61000-6-3:2007+A1:2011 & EN 61000-6-1:2007 Under the Council Directive 2004/108/ EC on Electromagnetic Compatibility.

